




Boat Cover Installation Instructions




- Place the bow end of the rolled cover on or near the bow of your boat and unroll towards the stern.
- Hook the front of the cover over the bow.
- Ensure the tow hook is positioned in the tow hook opening if applicable.



- Open the cover to the sides as you work towards the back of the boat.
- Install support poles as needed while unrolling the cover.




- Secure the cover over the rear of the boat (motor, swim platform, etc.)



- Zip all zippers

NOTE: Ensure both parts of the zipper are firmly seated at the bottom before zipping.



- Feed the loop end of the rope into the pocket and hook onto the ratchet.
- Slightly tension the ratchet.
- Check that the cover is secured properly on all corners.
- Pull the ratchet tight.

Releasing Ratchet Tension: If you have the Rope Ratchet under heavy tension, it can be difficult to release the thumb lever. Pull the free end of the rope, then push the thumb release. Pulling the free end of the rope takes tension off the wheel, making the thumb lever easier to release.

Storing the Cover: Fold the cover in on itself towards the middle of the boat from the sides and roll the cover from the rear of the boat towards the front (this will ensure your cover is ready to be reinstalled easily when needed again). Place the cover in your storage bag.